


# Lockpin Lowdown

Lockpins used to install the S-280 shelter tiedown kit on FMTVs are coming up short—they're not long enough to lock the stake pocket plugs in place. So what you really need is a longer pin.

No problem—here's the fix.

Just use the same pins without their split collar. Get a screwdriver and pliers from the No. 1 Common shop set to remove the split collar.

Without its collar, the lockpin is long enough to do its job.




LUMES...

## HOLD THAT CARGO LOAD!

Rear  
NSN 3940-01-477-6758

Front  
NSN 3940-01-477-7095



Back-tracking for lost cargo while driving the lightweight utility mobility enhancement system (LUMES, often referred to as an M-GATOR) isn't anyone's idea of a good time.

To keep cargo in place, use cargo net, NSN 3940-01-477-6758, for the rear, and net, NSN 3940-01-477-7095, for the front of the vehicle. That way you won't end up with a lost load!